



OmbraeTM system Manual

Assembly Instructions

Ombrae™ roller blinds



Recommended tools: a drill with bits suitable for the type of surface, a spirit level, a tape measure, a pencil, and a screwdriver or power screwdriver.



The installation must be completed using appropriate safety devices.



Before drilling, check that there are no pipes or electrical cables at the fixing point. Ensure that the chosen surface is strong enough to support the weight of the curtain and select screws and wall plugs suitable for the type of mounting.

Index

Installation


A - with roller bar	4
B - without roller bar	5
C - on window frame	6
Motorized	6

Use and maintenance 7


General information	8
Use	8
Maintenance and cleaning	9
Warranty	9

Assembly with mounting bar


A




- 1** Place the roller blind where it will be installed and mark the ends of the curtain rod.




- 2** Measure 10 cm from each end of the rod to locate and mark the clip attachment points. If the roller blind is wider than 1 m, additional clips will be provided, which should be spaced evenly across the width of the roller blind. Make sure the curtain is level while measuring.




- 3** Secure the clips with appropriate screws and anchors. If the roller blind is mounted on the wall, the tabs on the clips should face downward; if the roller blind is mounted on the ceiling, they should face toward the wall. Make sure the clips are properly aligned.



- 4** Position the awning in front of the clips and attach the roller bar to the clips, first inserting the top groove and then the bottom groove with the clip's tab until you hear it click into place. Make sure the bar is properly attached to all the clips and that the roller blind is level.




- 5** If the roller blind is manually operated, secure the chain guide to the wall with a screw, attaching it to the chain and making sure the chain is taut.




- 6** Make sure the awning is working properly. Once installed, leave the awning fabric fully extended for 24 hours.

Assembly *without* roller bar


B




- 1** Measure the width of the roller blind by measuring the distance between the two side brackets.




- 2** Transfer this measurement to the wall or ceiling, marking the positions of the two brackets. The brackets must be properly aligned; an incorrect distance or misalignment can interfere with the blind's operation.




- 3** Align the side brackets with the marks you made earlier and secure them using appropriate screws and anchors. Check that the brackets are properly aligned.




- 4** Place the included screw covers on the brackets and the selected covers.



- 5** Insert the tube with the fabric into the brackets, inserting the control side first until it locks into place, and then pressing the retractable spring pin to secure the other end.




- 6** Secure the chain tensioner to the wall with a screw, attaching it to the chain and making sure the chain is taut.




- 7** Make sure the awning is working properly. Once installed, leave the awning fabric fully extended for 24 hours.


Assembly on the window frame




- 1** Secure the clips to the hinged door brackets by tightening the screws and locking plates. The tabs on the clips must face downward.



- 2** Open the hinged sash and secure the brackets with the clips using the hex wrench provided, approximately 10 cm from the ends of the sash. Do not use excessive force to avoid damaging the threads and the window sash.



- 3** Position the curtain in front of the clips and attach the mounting bar to the clips, first inserting the top groove and then the bottom groove with the clip's tab until you hear a click. Make sure the bar is properly attached to all the clips and that the roller blind is level and centered relative to the window sash.



- 4** Once installation is complete, check that the window sash opens and closes freely, without the blind or chain interfering with the frame or other sashes. Once installed, leave the blind fully extended for 24 hours.

Motorized version

Installing the motorized version of the awning is no different from installing the manual version. Please follow installation instructions [A](#) [B](#) or [C](#).

To connect the motors to the electrical system and adjust the limit switches, read the instructions for the motor installed on your awning.

Do not cut or shorten the motor's power cord. For rechargeable battery-powered motors, fully charge the battery before first use. Work on the electrical system must be performed by qualified personnel.

Use and maintenance **Ombrae™ roller blinds**



Read the instruction manual carefully before use. If the system is motorized, read the motor's user manual.

General information

This manual has been prepared to prevent injury to people and damage to property, and to ensure the product's longevity and proper functioning over time.

This manual is an integral part of the product package: it must be kept in a safe place and made available for future reference until the product is disposed of. If the awning is sold, the manual must accompany it.

The complete product documentation consists of: this manual; any illustrated assembly instructions; and, for motorized products, the manuals for the motor and control accessories provided by their respective manufacturers.

Intended Use

The indoor roller blind is designed and manufactured to block sunlight and to regulate light levels and privacy within rooms. Any other use is considered improper. This product is intended for indoor use only: it must not be installed outdoors or exposed to the elements, direct wind, or significant fluctuations in humidity.

Prohibited Uses

- Hang, hook, or attach any load to the tent, the backdrop, or its components.
 - Use the tent as a support, prop, or safety device for people or objects.
 - Move the tent by yanking or making sudden movements.
 - Modify, tamper with, or remove components, particularly moving parts and electrical components.
 - Expose the fabric to heat sources or open flames, or apply stickers, tape, or substances to the fabric that could damage it.
- NOTE: Any use other than that intended may cause damage, void the product warranty, and relieve the manufacturer (SERAPLASTIC | CITEA) of all liability.

Installation Recommendations

It is recommended that installation be performed by qualified personnel, in full compliance with the instructions provided in this document and in the installation manual.

For mounting, use screws or anchors suitable for the type of support or wall on which the curtain will be installed. Verify that the installation surfaces are flat and square; if any misalignments are found, make the necessary adjustments.

Packaging, Handling, and Transportation

- The roller blinds are packaged in clear bags, cardboard, and polyethylene to protect them during shipping.
- When removing the roller blinds from its packaging, do not use sharp tools (scissors, utility knives): you risk cutting the fabric and compromising the product's functionality.
- During installation, keep the roller blind on a horizontal surface; under no circumstances should it be held in a vertical position.
- When handling the product, take all necessary precautions to prevent any damage.
- The roller blind can be handled manually and does not require the use of special equipment. For large products, it is recommended that two people handle them.
- After removing the packaging, check the roller blind for damage, ensuring there are no visibly damaged parts. If you have any doubts or notice any abnormalities, do not use the product and contact the supplier.
- Keep the packaging out of the reach of children (choking hazard) and dispose of it in the appropriate recycling bins according to local regulations.

Use

Manual operation

- When raising or lowering the fabric, do not apply excessive force to the operating chain to avoid damaging the components or the chain itself.
- Control the speed at which the fabric is lowered and raised to prevent it from winding improperly around the tube.
- Avoid unrolling the fabric completely to prevent damage to the roller blind.

Motorized operation

- Operate the roller blinds only with the controls provided, following the motor's instruction manual.
- Keep a safe distance during operation and do not obstruct the movement of the awning fabric.
- Do not operate the motor if you notice any malfunctions, unusual noises, or if the power cord is damaged.
- Keep remote controls and other control devices out of the reach of children.

Maintenance and cleaning

To clean the fabric, aluminum profiles, and plastic components, we recommend gently wiping them with a cloth dampened with water. Allow the fabric to dry completely before rolling it back up.

CAUTION: Using chemical products may damage the awning fabric or the finish of the other parts of the roller awning.

- Periodically check that the fasteners are tight and that the fabric and chain slide smoothly.

Assembly and disposal

At the end of its useful life, safely dismantle the awning and dispose of the materials in the appropriate recycling bins (aluminum, plastic, fabric). Motorized products contain electrical/electronic components and, if equipped with a battery, batteries: these parts are subject to the WEEE Directive (Directive 2012/19/EU) and must be disposed of separately at authorized collection centers; do not throw them in household trash.

Risks

- For manually operated blinds, be careful with the pull cord:
- During installation, it can pose a tripping hazard if the blind is temporarily resting on the floor;
 - During use, it can pose a suffocation hazard to children: install the included cord guard if the room where the blind is installed is accessible to children under 42 months of age.

For motorized blinds:

- Risk of entrapment/crushing while the blind is moving: keep a safe distance during operation.
- Electrical hazards: do not tamper with the motor or wiring; any repairs must be performed by qualified personnel.
- Do not allow children to play with the control devices.

Warranty

To ensure that all warranty conditions are met, do not attempt to disassemble any parts or accessories that may appear to be malfunctioning on your own; instead, contact your retailer, who will provide service and replacement parts. The warranty covers the replacement of the entire product or its parts in the event of operational defects resulting from manufacturing defects; however, it does not cover damage or deterioration caused by the customer. This awning is covered by a 12-month warranty from SERAPLASTIC | CITEA.

DoP

Il sottoscritto rappresenta il seguente costruttore:

SERAPLASTIC Srl

Via I Maggio 42, 24060 Telgate (BG)

Dichiara qui di seguito che il prodotto:

TENDE DA INTERNO - LINEA OMBRAE



Tende interne manuali: conformi al Regolamento (UE) 2023/988 sulla sicurezza generale dei prodotti e alle norme UNI EN 13120:2009+A1:2014 "Tende interne Requisiti prestazionali compresa la sicurezza", UNI EN 16433:2014 e UNI EN 16434:2014, con particolare riferimento alla "sicurezza in uso", inclusa la protezione dallo strangolamento.

Tende interne motorizzate: conformi alla Direttiva Macchine 2006/42/CE (marcatura CE) e alle norme UNI EN 13120:2009+A1:2014, UNI EN 16433:2014 e UNI EN 16434:2014, con particolare riferimento alla "sicurezza in uso", inclusa la protezione dallo strangolamento e dallo schiacciamento.

Telgate, 2026



SERAPLASTIC Srl
Direttiva 2006/42/CE

SERAPLASTIC Srl

Via I Maggio 42

Telgate (BG)

Prodotto: Tenda

Classe: NPd

Firma

XXXXX

(Ruolo)

Seraplastic | Citea

Via della Molinara, 49/C
24064 Grumello del Monte, BG
+39 035 830408
info@seraplastic.it

Via Druento, 286
10078 Venaria Reale, TO
+39 011 4246877
info@citea.it



www.citea.it

Ombrae[™] system manual
v1.0 | 2026

seraplastic | citea

